

1.

Start by installing
brackets CA1SSJ5

2. Use a tape measure to install the next
row of brackets through oval holes
with a span of 750 mm
Use a level to double check and align
the brackets

3. When in position fully fasten the brackets to the studs

When in position fasten
the brackets fully

5. Start installing the cassettes by hanging them onto the brackets
Continue by fastening the top flange to the studs
Make sure to use EPDM separating pieces CA3SP814
Use gap templates for that 10 mm vertical gap

Insert EPDM separating pieces
CA3SP814 into 10 mm fastening
holes in the top flange

4.